

(1) Vorbereitungen

Zur Montage von DESIGN-STEP ist eine planebene Treppenstufe vorzusetzen. Beachten Sie bitte die Ebenheitstoleranzen der DIN EN 18 202.

(2) Montage des Basisprofils:

Die Setzstufe wird mit dem ausgewählten Bodenbelag versehen. Beginnen Sie mit der untersten Stufe. Legen Sie anschließend das Basisprofil so auf die Stufenkante an, dass die Nase des Basisprofils über den Bodenbelag der Setzstufe greift. Schieben Sie das Profil stramm an die Kante an. Nun verschrauben Sie das Profil mittels der beigefügten Befestigungsschrauben in den zuvor gebohrten und mit Dübeln versehenen Löchern. Bei Holzstufen kann auf das Dübeln verzichtet werden. Verlegen Sie nun entsprechend den Herstellervorschriften den Bodenbelag auf der Trittstufe.

(3) Montage des Oberprofils:

Legen Sie das Profil auf an die Führungsnuten an und drücken es per Hand soweit es geht in diese ein. Nehmen Sie nun einen Schlagklotz und einen Kunststoffhammer und schlagen das Profil gleichmäßig an, bis dieses mit der Bodenbelagsoberfläche planeben abschließt. Das Profil sollte nun mit der unteren Seite ebenso wie mit der Auflageseite fest an dem Bodenbelag anliegen. Beachten Sie bitte, dass Korrekturen jetzt nicht mehr möglich sind.

(1) Preparations

To install DESIGN-STEP, a levelled staircase is required. Please consider the flatness tolerances of DIN EN 18 202.

(2) Mounting the base profile:

First the floor covering should be installed on the first riser. Start with the lowest step. Then apply the base profile, the nose of the base profile engages over the floor covering of the riser. Push the profile close to the edge. Now screw the profile into the previously drilled holes using the dowels and fastening screws provided. For wooden steps the base profile can be screwed on directly. Now lay on the floor covering onto the step according to the manufacturer's instructions.

(3) Installation of the top profile:

Adjust the profile on the guide grooves and push it in by hand as far as possible. Now take a slap block and a plastic hammer and hit the profile evenly until it is flush with the surface of the floor covering. The profile should now rest firmly against the floor covering with the lower side as well as with the support side. Please note that corrections are no longer possible.

