

Verlegehinweise

Laying instructions

(1a) Basisprofil verschrauben

Basisprofil auf dem Untergrund positionieren und Löcher markieren. Mit einem 5 mm Bohrer die Löcher für die Dübel bohren. Dübel einstecken, so dass sie vollkommen im Bohrloch verschwinden. Basisprofil mit den beige-packten Schrauben befestigen.

(1b) Basisprofil verkleben

Bei der Verklebung des Basisprofils ist darauf zu achten, dass der Untergrund frei von Trennmitteln ist. Es kann ein Zwei-Komponenten-Kleber oder ein Kleber mit besonders hoher Klebkraft verwendet werden. Nach der Verklebung des Basisprofils den überschüssigen Klebstoff glatt abziehen. Kleber vor der Verschraubung des Oberprofils vollkommen aushärten lassen.

(2) Oberprofil auflegen

Bei der Verlegung des Bodenbelages ausreichende Dehnungsfugen berücksichtigen. Das LPS Design Oberprofil so auflegen, dass der Führungssteg am Schraubkanal des Basisprofils anliegt.

(3) Oberprofil fixieren

Es sind drei Schraubenlängen beige-packt. Je nach Bodenbelagsstärke die korrekte Schraubenlänge auswählen. Die Torx-Schrauben mit einem Schraubendreher (Bit Torx T10) im Schraubkanal befestigen.

Demontage:

Die Schrauben können problemlos rausgedreht und wieder eingeschraubt werden.

(1a) Screw the base section

Position the base section on the surface and mark the holes. Drill the holes for the anchors using a 5 mm drill. Insert the anchors so that they will completely disappear in the drill hole. Fasten the basic section with the supplied screws.

(1b) Basic section gluing

When gluing the base section it is important to ensure that the surface is free of separating agents. You can use a two-component adhesive or adhesive with particularly high adhesive strength. After having glued the base section, the excess adhesive must be smoothly removed. Have the adhesive completely cured before fitting the upper section.

(2) Put on the upper section

Consider sufficient expansion joints when laying the floor covering. Put on the LPS design top section in such a way that the guide web lies against the screw channel of the base section.

(3) Fix the upper section

There are three different lengths of screws provided. Select the correct screw length depending on the thickness of the floor covering. Fasten the torx screws with a screwdriver (bit torx T10) into the screw channel.

Dismantling:

The screws can be easily removed and screwed in again.

